



## Rechargeable Electric Toothbrush

### ! IMPORTANT

Do not attempt to use the power supply/charger with any other product; do not attempt to operate this product with any other power supply/charger.

READ THESE INSTRUCTIONS CAREFULLY BEFORE USE AND SAVE FOR FUTURE REFERENCE

### Component list

1. Rechargeable toothbrush
2. 2 x toothbrush heads
3. Portable charging station
4. Wall mounting fixtures

### Connecting

- ▶ The charging unit can be connected to voltage outlet between 220-240 volts using a shaver socket outlet or adaptor socket BS1363/3.
- ▶ Place the rechargeable toothbrush handle onto the charging base (switch to the front).
- ▶ The green indicator will light up when the toothbrush is inserted on the plugged-in charging base.
- ▶ The toothbrush may warm up slightly during recharging. This does not effect the operation of the unit. Over charging is impossible.
- ▶ To maintain the toothbrush's full performance, it should always be stored on the charging base after use.

### Preserving the rechargeable batteries

- ▶ To maximise the capacity and life of the rechargeable batteries, they should be fully charged for 16 hours before the first use, fully discharged in use then recharged to full capacity again.
- ▶ This discharging/charging procedure should be done every 6 months.

### How to use

- ▶ After the toothbrush handle has been fully charged, attach the brush head to the handle by placing it on the unit twisted slightly to the left and turning to the right until it is locked into position. To remove, simply reverse the procedure. The brush head must face the same direction as the switch.
- ▶ Wet the brush head and place the toothpaste on the head. Switch the toothbrush on AFTER guiding the brush head into your mouth.
- ▶ Position the brush in an angled position and slowly move the brush along the outside and the inside surfaces of all your teeth and gums. Clean the rear sides and chewing surfaces of the molars with a rotary movement.
- ▶ The toothbrush will run for 2 minutes, as per the recommended brushing time by dental professionals. At exactly 2 minutes the motor will simply turn itself off.

During the first few days of using, your gums may bleed slightly, particularly if they normally tend to do so. After a few days, the bleeding will generally stop. If your gums continue to bleed after 2 weeks, you should see your dentist.

Brush heads should be replaced every 2 to 3 months depending upon use. If the bristles splay before 2 months this means that you are exerting too much pressure on your teeth and gums.

### ! IMPORTANT - Cleaning instructions

The following care instructions must be followed to ensure your toothbrush functions correctly:

1. After use rinse the brush head thoroughly for several seconds with the toothbrush switched on under running water.
2. Wipe away and remove all toothpaste residue from the head and handle after use as hardened toothpaste can lead to damage of the internal mechanism.
3. Dry handle.
4. Store toothbrush on charging base.

### Protecting the environment



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. Disposal can take place at appropriate collection points provided in your country.

## Correct disposal of this product

When the battery in the toothbrush handle is exhausted and will not accept any further charging it should be removed from the unit and disposed of in accordance with local regulations with respect to rechargeable batteries. Contact your local council to determine the correct procedure for disposal. Before disposing of the unit the battery should be removed as follows:

- ▶ The appliance must be disconnected from the supply mains when removing the battery.
- ▶ Before removing, the battery should be completely empty of charge. Let the appliance run until the motor stops.
- ▶ Using a suitable tool, turn base cap anti-clockwise until rotation stops. Gently prize off cap. Remove brush head and push inside unit neck to push out internal workings. The battery can then be removed.
- ▶ Only unscrew for battery removal.
- ▶ The remaining unit and charging base should be disposed of at an appropriate collection point and not disposed of with other household waste.

## Specifications

**Charging unit:** AC 220-240V, 50/Hz. 2W.

**Rechargeable power unit:** 2.4V, maximum operation time lasts up to 7 days between charges (2 min, 2 x/day) when fully charged.

**Note:** When the rechargeable cells are empty the toothbrush handle automatically turns off. This protects the rechargeable cells from deep discharging and signals that the toothbrush should be recharged.

## Wall mounting

- ▶ Put the screws and screw plugs provided into the wall.
- ▶ Slide the charging unit downward onto the screws.

## Important safeguards

When using any electrically powered product, basic safety precautions should always be followed, including the following:

**Warning - To reduce the risk of fire, electrical shock or injury to persons or property:**

- ▶ Always operate the product from a power source of the same frequency and rating as indicated on the product identification plate.
- ▶ The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the appliance by a person responsible for their safety.
- ▶ Adult supervision required for children under 6. Not intended for children under 3. **THIS IS NOT A TOY.**
- ▶ Do not operate this product if the power supply cord or plug is damaged. If the power supply cord is damaged the product should be disposed of as advised in these instructions.
- ▶ If the product malfunctions, is dropped or appears damaged in any way return the complete product to the address below. Do not twist, kink or wrap the power cord around the appliance, as this may cause the insulation to weaken and split, particularly where it enters the unit.
- ▶ To reduce the risk of electric shock, do not immerse or expose the power base or flexible cord to rain, moisture or any liquid other than those necessary for correct operation of the product.
- ▶ Never install or store the unit where it could be subject to:
  - Heat sources such as radiators, stoves or other products that produce heat,
  - Direct sunlight,
  - Excessive dust,
  - Mechanical vibration or shock,
  - Lack of ventilation such as in a bookcase or cabinet,
  - Uneven surface,
  - Do not use the appliance for other than its intended use,
  - This product is intended for normal domestic/household use only,
  - The use of attachments or accessories not recommended or sold by the product distributor may cause personal; or property hazards or injuries,
  - Only use Wisdom Power+ Pro Clean or Power Plus replacement heads.

## Warranty

- ▶ We grant 1 year manufacturer warranty on the product commencing from the date of purchase.
- ▶ Within the warranty period, we will repair or replace an appliance with material or manufacturing defects.
- ▶ The warranty does not cover; damage due to improper use, normal wear or use, foreign intervention or changes to the original state of the appliance as well as in the case of (inappropriate) industrial use.
- ▶ The warranty becomes void in the event that the appliance is opened or repairs are made by an unauthorised person.
- ▶ Please keep your till receipt safe as this will be required for validation of your warranty.
- ▶ To obtain service within the warranty period please send your appliance along with your original till receipt to:  
**Wisdom Toothbrushes Limited, The Silk Mill, Colne Valley Road, Haverhill, Suffolk CB9 8DT. Tel: 01440 714800.**

For further information on how to keep your toothbrush in a good condition, please visit our website.

All enquiries: Wisdom Toothbrushes Ltd, The Silk Mill, Colne Valley Road, Haverhill, Suffolk, CB9 8DT. Tel: 01440 714800

[www.wisdom-toothbrushes.com](http://www.wisdom-toothbrushes.com)

 /wisdomtoothbrushes

Healthy  
teeth.  
For life.  


2